

Wheel hangers set


FH-4WH




Thank you for purchasing our flush mounted wheel hangers.
This product is intended for storage of wheels with tires weighing up to **135lbs** each.
Please read these instructions from start to finish before beginning.
For any issues or questions contact support@fibrehead.com

- We are not liable for damages caused by improper installation or misuse of this product.
- Not recommended for Seismic zones 3 or higher. (earthquake zones)
- Always check/detect routing of pipes and electrical before penetrating/drilling walls.
- Clear the installation space of vehicles or valuables before beginning.

Parts Included



Hardware Included



Tools Required Not Included

Drywall with Wood Studs




Or

Masonry (concrete/brick)



Common




Any Issues or questions contact Support@fibrehead.com


Wood stud install

Skip to next section if installing into Masonry (Block or Brick)


Step 1. Locate and Mark Studs



Note:
For oversize tires
32" and larger.
Instead of a
straight line,
do a zigzag pattern
offsetting for
additional size.



Step 2. Pre-drill Bolt locations



1. Center top hanger hole over the marked locations and drill **3" deep**.
2. Repeat this for all 8 holes using the hanger as a template.
(you should see wood dust come out with the drill bit).




Drill



Safety Glasses

Step 3. Fasten bolts and test weight



1. Fasten all 8 Bolts using a ratchet.

2. Test each Hanger by pulling it up and down with one arm to make sure its securely in the stud.


3. Press plastic Caps over each Bolt Head
(to protects your wheels from scratching)



Masonry Install

Installing in Concrete, Block or Brick.


Step 1. Locate and mark holes.
(Hole center accuracy required so be precise)



Step 2. Drill Lag Shield locations



1. On center Mark, use a 1/2" Drill bit and drill to 3" deep.
2. Repeat this for all 8 holes
3. Insert Lag Shields ("Hole" label side first) Tap with Hammer into place.



Drill or Hammer drill




Safety Glasses



Hammer

Step 3. Fasten bolts and test weight



1. Fasten all 8 Bolts using a ratchet.


2. Test each Hanger by pulling it up and down with one arm to make sure its securely in the wall.

3. Press plastic Caps over each Bolt Head (to protects your wheels from scratching)



Hanging Wheels


Step 4. Remove center cap and
Hang wheels



X Incorrect X

Cutaway view
shown.

Always hang the
wheel face closest
to the wall



Correct

Finished!

Great job...Time for a beverage.

F.A.Q.

Q: What if my wheels don't have a center hub opening. (Some Corvettes)

A: Cover the hanger with the plastic bag it came in so it doesn't scratch your rims.

Hang the rim through one of its wedge openings , resting at the top.

Q. My Wall has steel studs. Can I still use the Hangers?

A: Follow same instructions as wood stud wall but Reduce the weight capacity to 50lbs

Q. My wheels and tires are too big and don't fit at the 32" spacing.

A: You must hang every other hanger lower (Zigzag pattern). Spacing will depend on wheel size.

Any Issues or questions contact Support@fibrehead.com